



The Zircon® Advantage

A Tool for Every Job

Be Alerted to Water Leaks at the Home, Condo, Apartment, Office Building or Work Space! Undetected water can cause thousands of dollars in damage. Minimize the cost and heartbreak and place a Leak Alert™ or Leak Alert™ WiFi smart detector anywhere the potential for flooding or leaks exist.

Leak Alert™ WiFi

Zircon PN #68882

Be alerted to leaks while at home or away.

Prevent serious water damage in your home with the help of the Leak Alert™ WiFi water detector. This self-contained battery-powered unit will send email alerts, sound a loud alarm, and flash red LED lights, the second it gets wet, alerting you to a potential water leak. Place it anywhere the potential for flooding or leaking exists:


- Near water heaters
- Under sinks
- Near washing machines
- In basements
- Near dishwashers and refrigerators
- Under fish tanks
- Near plumbing and toilets

- Wi-Fi connectivity—No hub required
- Loud alarm (105 dB) sounds for up to 8 hours
- Mobile, visual, and audio alert
- In the event of a flood, unit will float and continue to sound alarm until battery is depleted
- Fully automatic operation—no wiring required
- Low Battery Indicator for optimum safety and performance



Superior Customer Service

Zircon's team of Tool Pro Experts provide superior customer service. We know the ins and outs about tools, construction, and the challenges that DIYers and professionals face. Call 1 (800) 245-9265 (toll-free) Monday – Friday, 8am – 5 pm (PST) to reach live, knowledgeable, honest people who want to work with you. Zircon also provides users and merchants unparalleled support via an online 24/7 Interactive Support Center, step-by-step instructions, how-to videos, and online engagement. Visit www.zircon.com today.






Leak Alert™ 1 pk
Zircon PN #64003

Leak Alert™

Prevent serious water damage in your home with the help of Leak Alert™ water detector. This self-contained battery-powered unit will sound a loud alarm, and flash red LED lights, the second it gets wet, alerting you to a potential water leak. Place it anywhere the potential for flooding or leaking exists:

- Near water heaters
 - Under sinks
 - Near washing machines
 - In basements
 - Near dishwashers and refrigerators
 - Under fish tanks
 - Near plumbing and toilets
- Loud alarm (90 dB) sounds for up to 8 hours
 - Floats and signals for up to 72 hours
 - Fully automatic operation—no wiring required
 - Low Battery Indicator for optimum safety and performance



Leak Alert™ 5 pk
Zircon PN #69149